
LTE Terminal
LTE Network
UE
e Node B
HSS
MME
10:RRC Security Mode Complete
9:RRC Security Mode Command
6:NAS Security Mode Command
4:Authentication Request
1:Initial NAS Message
5:Authentication Response
7:NAS Security Mode Complete
11:S1AP Successful Outcome
8:S1AP Initiation Message
2:DIAMETER Authentication
3:DIAMETER Authentication